



**200065**

**ENGLISH**  
**Translation**  
**of the original instruction manual**



**Read these instructions before using and keep them available at all times!**

- 1. General information ..... 16**
  - 1.1 Information about the instruction manual ..... 16
  - 1.2 Key to symbols ..... 16
  - 1.3 Liability and Warrantees ..... 17
  - 1.4 Copyright protection ..... 17
  - 1.5 Declaration of conformity ..... 17
- 2. Safety ..... 18**
  - 2.1 General information ..... 18
  - 2.2 Safety instructions for use of the device ..... 18
  - 2.3 Intended use ..... 19
- 3. Transport, packaging and storage ..... 20**
  - 3.1 Delivery check ..... 20
  - 3.2 Packaging ..... 20
  - 3.3 Storage ..... 20
- 4. Technical data ..... 21**
  - 4.1 Overview of parts ..... 21
  - 4.2 Technical specification ..... 22
- 5. Installation and operation ..... 23**
  - 5.1 Safety instructions ..... 23
  - 5.2 Installation and connection ..... 23
  - 5.3 Operation ..... 24
- 6. Cleaning and maintenance ..... 27**
  - 6.1 Safety advice ..... 27
  - 6.2 Cleaning ..... 27
  - 6.3 Safety instructions for maintenance ..... 28
- 7. Waste disposal ..... 28**

Bartscher GmbH  
Franz-Kleine-Str. 28  
D-33154 Salzkotten  
Germany

phone: +49 (0) 5258 971-0  
fax: +49 (0) 5258 971-120

## 1. General information

### 1.1 Information about the instruction manual

This instruction manual contains information about the installation, operation and maintenance of the device and should be consulted as an important source of information and reference guide.

Awareness of the safety instructions and instructions for use in this manual will ensure the safe and correct use of the device.

In addition to the information given here, you should comply with any local Health and safety Controls and generally applicable safety regulations.

The instruction manual forms part of the product and should be kept near the device and easily accessible for anyone carrying out the installation, servicing, maintenance or cleaning.

### 1.2 Key to symbols

In this manual, symbols are used to highlight important safety instructions and any advice relating to the device. The instructions should be followed very carefully to avoid any risk of accident, personal injury or material damage.



#### **WARNING!**

*This symbol highlights hazards, which could lead to injury.*

*Please follow the instructions very carefully and proceed with particular attention in these cases.*



#### **WARNING! Electrical hazard!**

*This symbol draws attention to potential electrical hazards. If you do not follow the safety instructions, you may risk injury or death.*



#### **CAUTION!**

*This symbol highlights instructions, which should be followed to avoid any risk of damage, malfunctioning and/or breakdown of the device.*



#### **NOTE!**

*This symbol highlights tips and information, which have to be followed for an efficient and trouble-free operation of the device.*



#### **WARNING! Hot surface!**

*This symbol is a warning that the device surface is hot when in use. Ignoring this warning may result in burns!*

### 1.3 Liability and Warrantees

All the information and instructions in this manual take into account standard safety regulations, current levels of technical engineering as well as the expertise and experience we have developed over the years.

The instruction manual was translated with all due care and attention. However, we do not accept liability for any translation errors. The German version of this instruction manual is definitive.

If the delivery consists of a special model, the actual scope of delivery may differ from the descriptions and illustrations in this manual. This is also the case for special orders or when the device has been modified in line with new technology.



#### **NOTE!**

***Read this manual carefully and thoroughly before any operation of the device, and especially before turning it on!***

Manufacturer **is not liable** for any damages or faults caused by:

- violation of advice concerning operation and cleaning;
- use other than designed;
- alterations made by user;
- use of inadequate spare parts.

We reserve the right to make technical changes for purposes of developing and improving the useful properties.

### 1.4 Copyright protection

The instruction manual including any texts, drawings, images or other illustrations is copyright. No part of this publication may be reproduced, transmitted or used in any form or by any means without permission in writing from the manufacturer. Any person who commits any unauthorized act in relation to this publication shall be liable to claims for damages. All rights reserved.



#### **NOTE!**

***The contents, texts, drawings, pictures and any other illustrations are copyright and subject to other protection rights. Any person unlawfully using this publication is liable to criminal prosecution.***

### 1.5 Declaration of conformity

The device complies with the current standards and directives of the EU.

We certify this in the EC declaration of conformity.

If required we will be glad to send you the according declaration of conformity.

## 2. Safety

This section provides an overview of all important safety aspects.

In addition every chapter provides precise safety advice for the prevention of dangers which are highlighted by the use of the above mentioned symbols.

Furthermore, attention should be paid to all pictograms, markers and labels on the device, which must be kept in a permanent state of legibility.

By following all the important safety advice you gain an optimal protection against all hazards as well as the assurance of a safe and trouble-free operation.

### 2.1 General information

This device is designed in accordance with the presently applicable technological standards. However, the device can pose a danger if handled improperly and inappropriately.

Knowing the contents of the instruction manual as well as avoiding mistakes and thus operating this device safely and in a fault-free manner is very essential to protect yourselves from the hazards.

To prevent hazards and to ensure optimum efficiency, no modifications or alterations to the device that are not explicitly approved by the manufacturer may be undertaken.

This device may only be operated in technically proper and safe condition.

### 2.2 Safety instructions for use of the device

The specifications regarding the industrial safety are based on the Regulations of the European Union applicable at the time of manufacturing the device.

If the device is used commercially, the user is obliged to ensure that the said industrial safety measures concur with the state of the rules and regulations applicable at the time in question for the entire period of use of the device and to comply with the new specifications.

Outside the European Union, the industrial safety laws applicable at the place of installation of the device and the regional territorial provisions must be complied with.

Besides the industrial safety instructions in the instruction manual, the general safety and accident prevention regulations as well as environment protection regulations applicable for area of application of the device must be followed and complied with.



#### **CAUTION!**

- The device can be used by children **8 years and up**, as well as by people with disabilities and those with limited experience/knowledge as long as they are under supervision or have been instructed on proper use of the device and its possible dangers.

- **Children** should not play with the device.
- Cleaning and **maintenance cannot be performed by children** younger than 8 years old and must be done under supervision.
- **Children under the age of 8 years old** must be kept away from the device and its power cord.
- Please keep these instructions and give them to future owners of the device.
- All people using the device should follow the instructions and tips contained in these instructions.
- Only use the device indoors.

## 2.3 Intended use

Safe operation is only guaranteed when using the device for its intended purpose.

Any technical interventions, as well as assembly and maintenance are to be made by a qualified customer service only.

The device is intended for home use or in similar places such as:

- in kitchens for store or office employees or in other service locations;
- in suburban properties;
- by guests of hotels, motels and other places of accommodation;
- in Bed & Breakfasts.

The **mulled wine pot** is designed **only** for **heating up and keeping warm** drinkable liquids such as mulled wine, punch, jagertee.

The **mulled wine pot** must **not** be used for:

- boiling of water or food;
- keeping warm and heating up inflammable, harmful to health, easily volatilizing or similar liquids or substances.



### **CAUTION!**

***Any use going beyond the intended purpose and/or any different use of the device is forbidden and is not considered as conventional.***

***Any claims against the manufacturer or his authorized representative as a consequence of experiencing damages resulting from unconventional use are impossible.***

***The operator is liable for all damages resulting from inappropriate use.***

## 3. Transport, packaging and storage

### 3.1 Delivery check

Please check the delivery upon completeness and transport damage immediately after receipt. In case of visible damage do not accept or accept the delivery with reservation only.

Note the extent of damage on the carrier's bill of delivery. Trigger off the complaint.

Hidden damages should be reclaimed immediately after notice, as claims for damages can only be asserted within the effective period for complaints.

### 3.2 Packaging

Please do not throw away the covering carton of your device as it might be useful for storage purposes, when moving or, in case of damages, when the device must be sent back to a repair center. The outer and inner packing material should be removed completely from the device before installation.



#### **NOTE!**

***If you liked to dispose the packing, consider the regulations applicable in your country. Supply re-usable packing materials to the recycling.***

Please inspect the device upon completeness. In case any part is missing please contact our customer service center immediately.

### 3.3 Storage

Keep the package closed until installation and under consideration of the outside indicated positioning- and storage markings.

Packages should be stored under consideration of the following:

- Do not store outdoors.
- Keep it dry and dust-free.
- Do not expose it to aggressive media.
- Do not expose it to direct sunlight.
- Avoid mechanical shocks and vibration.
- In case of longer storage (> 3 months) make sure you check the state of the packaging and the parts regularly.

If required refresh or renew.


## 4. Technical data

### 4.1 Overview of parts



- ① Lid handle
- ② Lid
- ③ Container handle
- ④ Container
- ⑤ Base
- ⑥ Operating elements
- ⑦ Drain tap

## Operating elements



- ⑧ Function switch
- ⑨ Power indicator lamp (red)
- ⑩ Setting mark (device)
- ⑪ Temperature control knob

## 4.2 Technical specification

Name	Mulled wine pot 7L
Code-No.:	<b>200065</b>
Material:	Body and lid: stainless steel; lid handle, container handles: plastic
Temperature range:	30 °C – 80 °C
Capacity:	7 litres
Power:	220-240 V 50 Hz 1850-2200 W
Size:	Ø 220 mm, height 490 mm
Weight:	2,0 kg

We reserve the right to make technical changes!

## 5. Installation and operation

### 5.1 Safety instructions



**WARNING! Risk of electric shock!**

***The device must only be connected to a properly installed single socket with protective contact.***

***Never remove the power cable by pulling the cable itself; always grab the plug housing.***

- Never allow the power cable to come into contact with heat sources or sharp edges. The power cable should not hang over the side of the working surface. Ensure that no one can step on or trip over the cable.
- The power cable must not be folded, bent or tangled, and must always remain fully unrolled.
- Never place the device or other objects on the power cable.
- Do not lay the cable over carpets or heat insulations. Do not cover the cable. Keep away the cable from operating range and do not dunk it into water.
- Do not use the device in case it does not function properly, has been damaged or dropped.
- Do not use any accessory or spare parts that have not been recommended by the manufacturer. These can be dangerous for the user or lead to damages of the device or personal injury, and further, the warranty expires.
- Do not move or tilt the device when in operation.
- Protect the device from frost and moisture.
- **Never** use the device with wet or moist hands.
- **Never** leave the device unattended when in use.

### 5.2 Installation and connection

- Unpack the device and remove all packing material.
- Put the device in a safe place that can support its weight and is not heat sensitive.
- **Never** place the device at the edge of a table to avoid accidents.
- **Never** put the device in a moist or wet area.
- Do not place the device near an open flame, electric heater or other heat source.



**WARNING! Hazard via electrical current!**

*The device can cause injuries due to improper installation!*

*Before installation the local power grid specification should be compared with that of the device (see type label). Connect the device only in case of compliance!*

*Take note of the security advice!*

- The electrical circuit of the socket must be secured to at least 16A. Only connect the device to a wall outlet; do not use any extension cords or power strips.
- Place the device so that the plug is easily accessible so as to quickly disconnect the device if the need arises.

## 5.3 Operation

- Before using the device, clean it according to the instructions contained in 6.2 „Cleaning“.
- Before pouring liquid and connecting the device, turn the temperature dial counter-clockwise to the counter-clockwise to the setting marked ►, and turn the function switch to **OFF** (at the top).
- Pour the desired amount of **beverage into the device up to the „MAX“ symbol. Do not exceed the maximum fill level!**
- Ensure that **drinkable liquid** is always inside the device before turning it on. The device may not contain **any liquid unsuitable for drinking**, such as acids, bases, oils, etc.!
- Place the lid on the device and ensure that it locks in place with the handles.



**WARNING!**


*When the device is in use, ensure that no liquid splashes, as this could lead to disturbances in electronic components and to personal injury.*

The device is equipped with **two functions**:

- **Heating:** heats liquids to approx. 80 °C
- **Boiling:** for boiling water

## Heating

- Pour the desired liquid into the device's tank (e.g. mulled wine, punch, tea, water).
- Ensure the function switch is in the **OFF** position (at the top).
- Insert the plug into a single grounded outlet. The red control light will come on.
- Use the temperature dial to set the desired temperature between 30 °C and 80 °C.
- Liquid inside the tank will be heated to the desired temperature.



## **NOTE!**

**Heating time depends on the type and volume of liquid.**

- After the desired temperature is reached the red control light will go off and the device will maintain the set temperature of the beverage.
- If the temperature inside the tank drops, the thermostat will activate the device and the beverage inside will again be heated to the set temperature and the red control light will come on.
- Before pouring more liquid into the device, turn the temperature dial counter-clockwise to the setting marked ►, carefully remove the lid and pour the desired amount of liquid into the tank.




**WARNING! Danger of burns!**

**Never remove the lid during heating!**

**Escaping steam may cause injury to hands, arms and eyes!**

## Boiling

- To boil water, fill the tank with the desired amount of potable water and set the function switch to **ON** (at bottom). The red control light will come on.
- After boiling temperature has been reached, the heating coil will automatically shut off and the function switch will move to the **OFF** position. The red control light will go off. The water's temperature will **not be maintained automatically**. To heat the water again, put the function switch in the **ON** position (at bottom).



- To distribute prepared hot beverages, place an appropriate dish (cup, mug, etc.) under the spout. Press and hold the lever down until the desired amount of beverage has come out. Release the lever to automatically close the spout.



### **CAUTION!**

**Regularly monitor the level of liquid and refill as necessary. Never use the device without liquid!**

- The device is equipped with a function protecting it against **overheating/operating when dry**. If the device is accidentally turned on without liquid or with too little liquid, the protection function will be activated and the device will be automatically shut off.

Leave the device to cool and pour any remaining beverage through the spout into another container.

Press the **RESET** button located at the bottom of the device base. The may now be filled with a beverage and operated normally.



- When finished using the device, turn the temperature dial counter-clockwise to the counter-clockwise to the setting marked ► (or move the function switch up to the **OFF** position), disconnect the device from its power source by removing the plug, leave to cool and then pour out any liquid still inside.

## 6. Cleaning and maintenance

### 6.1 Safety advice

- Before beginning with repair or cleaning works make sure the device has been disconnected from power supply and has cooled down.
- Do not use any acid agents and make sure no water ingresses the device.
- To protect yourself from electric shock, **never** immerse the device, its cables and the plug in water or other liquids.



#### **CAUTION!**

*The device is not suited for direct washing via water jets.*

*Therefore, you must not use any kind of pressure water jet for cleaning the device!*

### 6.2 Cleaning

- Clean the device regularly after each use.
- Clean the container from the inside with a mild detergent and rinse it with fresh water thoroughly.
- In order to clean the drain tap, pass water with detergent through it a few times and then rinse it with water to remove completely detergent residues.
- Do not use **steel wool** for cleaning. Small pieces may come loose and be deposited in the drain valve and damage the sealing surfaces.
- Clean the lid under warm running water and then rinse it with clean water.
- Wipe the outer part of the device with a damp, soft cloth. Use a mild detergent, if necessary.
- Use only a soft cloth and **never** use any kind of abrasive cleaners which could scratch the surface.
- **Never** use flammable cleaning agents (alcohol, etc.), as there is an increased risk of fire or explosion during restart of the device.
- If scale or other residues are deposited on the bottom of the container, remove them with conventional solutions. Please observe the instructions of the manufacturer.
- After cleaning, use a soft, dry cloth to wipe dry and polish the surface.

## 6.3 Safety instructions for maintenance

- Inspect the power cable regularly for damage. Never use the device if the cable is damaged. If the power cable is damaged, have an authorised service center or qualified electrician replace it.
- In case of damage or malfunction, please contact your stockist or our customer service centre.
- Only a qualified technician and using original spare parts and accessories should carry out repairs and maintenance of the device. **Do not attempt to repair the device yourself.**

## 7. Waste disposal

### Discarding old devices

At the end of its service life the discarded device has to be disposed in accordance with the national regulations. It is advisable to contact a company which is specialized in waste disposal, or just contact the local disposal service in your community.



### **WARNING!**

***To exclude any abuse and the dangers involved make the waste device unfit for use before disposal. For that purpose disconnect device from mains supply and remove mains connection cable from the device.***



### **NOTE!**



***For the disposal of the device please consider and act according to the national and local rules and regulations.***

Bartscher GmbH  
Franz-Kleine-Str. 28  
D-33154 Salzkotten  
Germany

phone: +49 (0) 5258 971-0  
fax: +49 (0) 5258 971-120